

## Embedment puck

Mounting



Drill 3 X Ø6 hole, fixing it with 3 screws



Push down the acrylic staff

