RobLight

Pyxis 1n

User manual

RobLight

Install

1. Drill

Ø22 [7/8"]

2. Install

I

II

RobLight

3a. Connect driver with fixed wires

Driver connection is inicative.
Please follow national rules
for connecting Class II luminaire.

Connect to mains.

Attention!
Always disconnect the driver
from mains power before connecting
or disconnecting of any fixture.

Class 2
CONSTANT CURRENT

SEC
350 mA+
CONSTANT
CURRENT

+ Red

- Black

+ Red

- Black

RobLight

3b. Connect driver with screw terminals

Driver connection is inicative.
Please follow national rules
for connecting Class II luminaire.

SEC
350 mA+
CONSTANT
CURRENT

Attention!
Always disconnect the driver
from mains power before connecting
or disconnecting of any fixture.

Class 2
CONSTANT CURRENT

+ Red

- Black

+ Red

- Black

RobLight

4. Change reflector or PCB
   Remove reflector

Ⅰ

Ⅱ

Ⅲ

Ⅳ

RobLight

5. Remove reflector fixture

(I)   Turn off mains power

(II)

(III)

(IV)

RobLight

8. Remove PCB

7. Replace PCB

RobLight

8. Insert reflector fixture

I

II

8. Insert reflector

RobLight

RobLight A/S, Gl. Skagensvej 105 H, DK-9900 Frederikshavn
T: +45 9244 4888, E: info@rob-light.com
www.rob-light.com